


LEGENDA:



ČK1 čitač kartica
CARD READER




Rex taster
REX BUTTON

EB1

Elektromagnetna brava
ELECTROMAGNETIC DOOR LOCK

EB1

Električna brava
ELECTRIC DOOR STRIKE



Otvaranje u slučaju nužde - ključem
EMERGENCY OPENING LOCK



Kontroler pristupa
ACCESS CONTROL DEVICE