

01 PV GENERATOR RISER DIAGRAM GT-E01REF:GT-E01 SCALE: NTS GENERAL NOTES:

- 1. THE SERIES CONNECTION OF PV PANEL SHALL BE ACCOMPLISHED BY MULTI CONTACT MC-IV CONNECTORS.
- 2. EACH SOLAR PANEL SHALL HAVE MANUFACTURER PROVIDED IP 67 JUNCTION BOX FOR PV PANEL TERMINALS EQUIPPED WITH FUSE.
- 3. FOR INVERTERS SHALL DANGER SIGN WHICH STATES: DANGER MULTIPLE SOURCES CONNECTED, DISCONNECT ALL SOURCES BEFORE SERVICING.
- 4. THE SOLAR SYSTEM IS ONLY FOR LIGHTING, COMPUTERS, PRINTER/COPIER.